



## M-2087

### Leg press ESSENCE



VÍDEO



#### TECHNICAL SPECIFICATIONS:

- 3 mm reinforced steel chassis
- 200<sup>g</sup> polyester powder coating, black matt finishing.
- Steel transmission pulleys with ball bearings.
- High resistance power cable tensor built.
- Thermoformed weight-stack cover, aluminium effect.
- Tray for objects on the top.
- Antibacterial upholstery MRSA Standard, SANITIZED, Fireproof M2 Standard, UNE 1021, absence of solvents and noxious substances OEKO-TEX Standards.
- Red-trimmed upholstery.
- Pushing group sliding through ball bearing guide to ensure smooth and quiet movement.
- 5-position stainless steel goniometer to adjust starting position / angle of the exercise.
- Non-slip rubber covered grips.
- Reinforced non-sliding large platform.
- Stainless steel plate guides.
- 10 kg weight plates with low friction bushings.
- Load selector with magnetic security system.
- Adjustable levelers.
- Workload: 200 kg.
- Descriptive pictogram of the exercise.
- QR code that provides link to instructional video.
- Dimensions: 210x104x157 cm.
- Commercial use.

[www.salter.es](http://www.salter.es)

Due to constant innovation of our items, technical details of this item may slightly differ.

